



Instruction for PAIRING CONTROLLER with battery



When battery is not connected to load,
Push two buttons at the same time.



Now battery shall display "A" in flashing,



Push OFF button in wireless controller.



Now battery display shall be OFF,
or in display "F" in flashing.

Wireless controller is not able to match
with battery when the battery keep
displaying "A" and doesnot response to
the push in wireless controller.